

2 — 1. EDIT FAMILY

3 — 2. EDIT USER 1

4 — 3. EDIT USER 2

5 — 4. EDIT USER 3

6 — 5. EDIT USER 4

BACK HELP

FAMILY SPENDING LIMIT

FAMILY CAN SPEND UP TO
\$.00 PER EVENT

TWO LINES OF CONTEXT-SENSITIVE HELP WILL
BE POSITIONED HERE OVER THE BLACK BOX.

FIG. 1A
PRIOR ART

7 — 7. SPENDING LIMITS

BACK HELP

USER 1 SPENDING LIMIT

USER 1 CAN SPEND UP TO
\$.00 PER EVENT

TWO LINES OF CONTEXT-SENSITIVE HELP WILL
BE POSITIONED HERE OVER THE BLACK BOX.

FIG. 1B
PRIOR ART




FIG. 2





FIG. 3



PROGRAM GUIDE				5:00PM	5:30PM	6:00PM	6:30PM
FOUR WEDDINGS AND A FUNERAL							INTERNET E-MAIL
7/22							
CNN	WORLDVIEW				MONEYLINE		CROSSFIRE
ESPN	UP CLOSE	SPORTSCENTER			ESPN.com		UP CLOSE
HSN	GARDEN...	HOME FU...			BUYER'S M...		SHOWCASE
USA	RENEGADE				WINGS		WINGS
CNBC	BUSINESS...	BUSINESS...			MONEY CL...		FOUR WE...
HBO	APOLLO 13						HOLLYWO...
MTV	SINGLED OUT	TOP 10 VIDEO			COUNTDO...		BEAVIS & ...
EXIT	?						MENU

FIG. 5





FIG. 6

700



206-001

0 GO BACK ?

701 1 EDIT FAMILY

702 2 EDIT ANTHONY

703 3 EDIT CAROLYNN

704 4 EDIT MARK

705 5 EDIT VALERIE

SPENDING LIMIT

CAROLYNN CAN SPEND UP TO
\$.00 PER EVENT 710

SET A MONTHLY SPENDING LIMIT?

☐ YES

☒ NO

\$.00 PER MONTH 720

FIG. 7A

BACK HELP

1 NAME

2 EDIT CHANNELS

3 ADD ALL CHANS

4 DELETE ALL CHANS

5 SET RATING LIMIT

6 VIEWING HOURS

7 SPENDING LIMIT

8 LOCK USER

CAROLYNN CAN SPEND UP TO
\$.00 PER EVENT

SET A MONTHLY SPENDING LIMIT?
☐ YES
☒ NO

\$.00 PER MONTH

ROLLING PERIOD

TWO LINES OF CONTEXT-SENSITIVE HELP WILL
BE POSITIONED HERE OVER THE BLACK BOX.

750

FIG. 7B

TIME BASED SPENDING LIMITS

801 ☒ DAILY SPENDING LIMIT \$ 1 0 0

802 ☐ WEEKLY SPENDING \$

803 ☒ MONTHLY SPENDING \$ 3 0 0

804 ☐ YEARLY SPENDING LIMIT \$

☐ ROLLING PERIOD(S)

FIRST, PUT A CHECK IN THE BOX NEXT TO EACH SPENDING LIMIT YOU WANT TO USE. THEN USE THE NUMBER KEYS TO ENTER THE AMOUNT YOU WANT TO USE AS THE LIMIT.

FIG. 8

THE REQUESTED PURCHASE EXCEEDS A
TIME-PERIOD SPENDING LIMIT.

TO COMPLETE THIS PURCHASE, PRESS "CONTINUE"
AND ENTER THE SYSTEM PASSWORD.

TO EXIT THIS SCREEN, PRESS "CANCEL"

FIG. 9